



V E L O C I T Y

**Step 1:**

Use the supplied alcohol pads to thoroughly wipe down the areas where the adhesive tape from the tail light trim will contact the tail light (shown in RED in the below photo).



**Step 2:**

Peel the backing from the 3M tape as shown below.





VELOCITY

**Step 3:**

Place the trim over the tail light but do not fully press down yet. Once you are certain that the trim is aligned properly over the tail light, press down on all areas of the trim to fully seat the adhesive tape.



**Step 4:**

Complete Steps 1-3 for opposite side trim to complete the installation.